

實物投影機隱私權開啟步驟



4.

The screenshot shows the Windows Settings application. On the left is a navigation pane with categories: 首頁 (Home), 尋找設定 (Search settings), 隱私權 (Privacy), Windows 使用權限 (Windows permissions), 一般 (General), 語音、筆跡與輸入 (Speech, handwriting, and input), 診斷和意見反應 (Diagnostics and feedback), 活動歷程記錄 (Activity history), 應用程式使用權限 (App permissions), 位置 (Location), 相機 (Camera), and 麥克風 (Microphone). The '相機' (Camera) option is circled in red. The main content area is titled '相機' (Camera) and contains the following sections: '允許存取此裝置上的相機' (Allow apps to access your camera) with a '變更' (Change) button; '允許應用程式存取您的相機' (Allow apps to access your camera) with a toggle switch set to '開啟' (On), which is circled in red; and '選擇可存取您相機的應用程式' (Choose which apps can access your camera) with explanatory text. A red arrow points from the '相機' option in the navigation pane to the '相機' title in the main content area. Another red arrow points from the '開啟' toggle switch to the text '允許應用程式使用您的相機 改為「開啟」'.

點擊「相機」

允許應用程式使用您的相機
改為「開啟」